



## Trunk Protection

Urban Forest Manager Approved Tree  
Protection Detail

### Notes:

- Boards only need to be installed on the activity side of the trunk, but the cable must be padded so as not to come in contact with tree trunk.
- Boards must be an appropriate length to adequately protect tree from equipment.

(Not drawn to scale)

Closed-cell foam or similar padding material

2" x 6" wooden boards or similar material placed vertically on trunk, with maximum spacing of 4"

Boards are strapped with metal cable or similar durable securing implement

